



## Product information and directions for use VLOSEPT

Product name : VLOSEPT  
Purpose : To disinfect washwatertanks and transport rollers photo- and filmprocessors.  
Packing volumes : 4 plastic bottles of 1 liter per box

Washwatertanks and transport rollers of photo- and filmprocessors become contaminated with micro-organisms after some time. Besides the contamination of the films or photo's also bad smells and the danger of infections arise. Because of the building of slime and acid (corrosion!) as a result of the metabolism products of the micro-organisms the processor can malfunction.

By using of VLOSEPT washwatertanks and transport rollers are cleaned and disinfected. To prevent the building of micro organisms after cleaning it is advised to add VLOCLEAR to the washwater regularly. For further information is referred to the concerned information or to your dealer.

### DIRECTIONS

1. During the cleaning of the processor no films or photo's can be developed.
2. Add 1 bottle of VLOSEPT to the washwatertank of the processor, the transport rollers remain in the washwatertank. One bottle of VLOSEPT is sufficient for the cleaning of a tankvolume of 50 liters. In case the volume of the washwatertank is larger more VLOSEPT should be added accordingly.
3. By using the circulation pump of the processor the solution needs to be pumped around for at least one hour. Depending of the level of contamination this length of time can be extended, this does not damage the processor. In case filters are mounted it is advised to remove them and to replace them by new filters after cleaning. In case a WATER-OPTIMIZER is connected and also treated the columns have to be removed.
4. When the washwatertanks and the processor rollers are cleaned the cleaning water can be drained. In the advised dilution Vlosept is biodegradable.
5. The washwatertank and the transportation rollers should be rinsed with fresh water before the processor is put in use again.

### CAUTION

Concentrated VLOSEPT contains potassium hydroxide. In case of skin contact serious burns can arise. SKIN OR EYE CONTACT: Flush thoroughly with water and consult a physician. Wear suitable gloves and protection for the eyes or face. Polluted clothing needs to be taken off immediately.

Safety-data-sheets are available on request.

SAMA Water Products BV  
Archimedesstraat 12  
NL 3316 AB Dordrecht  
The Netherlands  
Telephone : +31-78-6393790  
Email : [info@samawaterproducts.com](mailto:info@samawaterproducts.com)